SUBWOOFER

SW-18HT

SERVICE MANUAL

KENWOOD

©2004-5 PRINTED IN KOREA
B51-5896-10 (Z/K) 153

EXTERNAL VIEW



CAUTION: THE GRILLE ASSY CANNOT BE REMOVED.

SPECIFICATIONS

Enclosure ..... Bass-reflex type
Loudspeaker ..... Woofer 160 mm (6-1/2") cone type
Impedance ..... 8 Ω
Maximum input power ..... 80 W
Sensitivity ..... 83 dB/W at 1m
Frequency response ..... 40 Hz ~ 700 Hz
Dimensions ..... W : 175 mm (6-7/8")
H : 400 mm (15-3/4")
D : 306 mm (12-1/16")
Net Weight ..... 5.2 kg (11.5 lb)

Note:
KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

70%

DISASSEMBLY FOR REPAIR/DIVIDING NETWORK UNIT/PARTS LIST

DISASSEMBLY FOR REPAIR

Replacing the grille ass'y or woofer
To remove the grill ass'y from the cabinet, cut the cloth covering the grille ass'y and take it out as shown in the following figure.



DIVIDING NETWORK UNIT



PARTS LIST

∗ New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Address	New Parts	Parts No.	Description	Destination	Remarks
			SW-18HT			
-		*	B06-1786-08	GRILLE ASS'Y		
-		*	B61-1212-00	INSTRUCTION MANUAL		
-			E21-0903-08	PUSH TERMINAL		
-		*	E30-7059-05	SPEAKER CORD		
-			G13-1187-08	CUSHION(ACCESSORY)		
-		*	H10-8435-08	POLYSTYRENE FOAMED FIXTURE		
-		*	H51-2055-08	ITEM CARTON CASE		
SP1		*	T10-1247-05	WOOFER		